

Swageless Fitting Installation Instructions

1. Place the cable through the main body of the fitting.
2. Insert the copper sleeve to the center strand and spread all wires around the sleeve evenly.
3. Adjust the wire to the same level and push the wire and sleeve down.
4. Place the wedge on top of the copper sleeve and wire. (For 3/8" cable size, the additional round cylinder part should be placed on top of the sleeve before placing the wedge.)
5. Place the top cap and tighten with wrench.
6. You are ready to go.

Note: Before installation, make sure each fitting has one piece of copper sleeve and one piece of wedge inside.

